

Siebel Center 3403

Turning the System On

- Press the power button once.
- The buttons will flash for approximately 30 seconds as the projector starts up. You may now select a source (The Apple TV is the default source).

Note: The system must be turned on before sources can be selected.

Using a Laptop

- Connect your laptop to the end of the VGA cable that is not connect to the input panel.
- Select the **[Computer]** button on the control panel.

Note: The input panel on this system has two VGA ports. One is labeled **[Input] and the other is labeled **[Monitor]**. Ensure the VGA cable is plugged into the **[Input]** port.**



Control Panel

Using a Composite Video Device

- Connect an RCA cable (user provided) between your device and the composite video ports on the input panel.
- Select the **[Composite Video]** button on the control panel.

Turning the System Off

- Press and hold the power button for 6 seconds.
- The buttons will flash for 30-90 seconds as the system shuts down.