

Siebel Center 4407

Turning the System On

- Press the [Power] button, on the control panel, once.
- The buttons will flash for approximately 30 seconds as the projector starts up. You may now select a source.

Note: The system must be turned on before sources can be selected.

Using a Laptop

- Connect your laptop to the end of the VGA cable that is not connected to the input panel.
- Select the [Computer] button on the control panel corresponding to the cable used to connect the laptop.

Note: Depending on your laptop model, you may need an adapter. Adapters can be borrowed on short term loan (4hrs.) from an Engineering IT Help Desk.

Turning the System Off

- Hold down the [Power] button till light starts flashing
- The buttons will flash for 30-90 seconds as the system shuts down.

(217) 333-1313 engrit-av@illinois.edu http://it.engrineering.illinois.edu